



Porodo Gaming E-Sports Desk Lamp with Charging Base


SKU: PDX119

Table of Contents

Schematic View	2
Specifications	2
Precautions	3
Package Contents	3
Connecting To Power	3
Instructions for Use	4
Wireless Charging Function	4
Viewing Angle Adjustment	5
Warranty	6
Contact Us	6

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Schematic View




Specifications

Input	12V/2.5A
USB Output	5V/2.1A
Wireless Output	10W Max
Power Cord	UK 3-Pin Plug
Luminous Flux	250±50 LM (Cool Light), 50±200 LM (Warm Light), 500-400 LM (Cool and Warm Light)
Color Temperature	5000±283 K (Cool Light), 283±3000 K (Warm Light), 500-400 LM (Cool and Warm Light)
Lamp size	183×124×534mm


Precautions

- 1. When using the wireless charger alone, it operates at 10W. This will automatically reduce to 5W when the main light is turned on simultaneously.
- 2. Clean the surface with a soft cotton fabric. Avoid using any corrosive solvents to prevent damage.
- **3.** The light source is not replaceable. Discontinue use when it reaches the end of its lifespan.
- 4. Do not attempt to disassemble the product yourself to avoid causing damage.



Connecting To Power

Insert the adapter into the DC port. Upon connecting to power, the RGB/LED will display in a curtain pattern, and the wireless charger's indicator will simultaneously light up in red and green.




Caution

1. The flexible cables on the exterior of the lamp are non-replaceable. Discontinue use of the lamp if these cables become damaged.

2. Avoid using the lamp on surfaces with its angle exceeding 6 degrees to ensure stability and safe operation.

Instructions for Use



A. LED Light Adjustment

- 1. On/Off: Quickly press the -X- button to toggle the LED light on or off.
- 2. Color Temperature: Press and hold the -\(\overline{\chi}\)- button to cycle through Cold Light, Warm Light, and Combined Cold/Warm Light settings.
- **3.** Brightness: Press the \wedge button to increase brightness or the \vee button to decrease brightness.

B. Colorful Light Adjustment


Short press the button to switch between the following modes: Colorful, Follow Spot, Gradual Change, Acoustical 1, and Acoustical 2.

C. Simultaneous Operation

Wireless Charging Function


Place devices that support wireless charging onto the designated charging area. A red indicator signals that charging is in progress. A green indicator means the device is fully charged.

Note: For phone charging, the indicator will turn green only if the phone sends a fully charged signal; otherwise, the indicator will remain red even if the phone is fully charged.



Viewing Angle Adjustment

Adjust each panel up to 90 degrees for optimal viewing. Ensure the angles are within the specified range to avoid damaging the connections. Adjusting beyond 90 degrees is not recommended and may cause damage.





Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo