

Porodo Gaming Omni-Directional USB Microphone

SKU: PDX550

Table of Contents

Overview	2
Specifications	2
Compatibility	3
Button Function Guide	3
Setup Guide	3
Troubleshooting	4
Disposal	5
Warranty	5
Contact Us	5

Overview

- 1. This microphone is expertly designed for specific applications such as web conferences, broadcasts, and interviews.
- 2. It features a professional USB 2.0 sound chip, ensuring compatibility with both Windows and Mac operating systems. It requires no drivers and supports plug-and-play functionality.
- 3. Equipped with an omnidirectional microphone, it offers 360-degree voice pickup without any dead angles, resulting in clearer audio capture.
- 4. Includes a push-button noise-canceling switch that effectively reduces ambient noise, enhancing audio clarity.
- **5.** Fitted with bottom pads to prevent the microphone from sliding and to minimize the impact of table vibrations.
- 6. Compact and portable, this microphone is simple to operate, making it perfect for web conferences, recording, or working from anywhere at any time.
- 7. Features a cool dynamic RGB light effect that adds aesthetic appeal to its functionality.


Specifications

Microphone Size	Ø6.0×5.0mm
Directivity	Omnidirectional
Frequency Response	100 to 16kHz
Sensitivity	-32±2dB (0dB=1V/Pa, 1kHz)
Impedance	800Ω to $2.2k\Omega$
Interface	USB 2.0
Cable Length	1.8M
Product Weight	205g
Compatibility	Windows, Mac

Compatibility

This product is compatible with both Windows and Mac OS systems.


Button Function Guide



Setup Guide

1. Connection Setting

Connect the microphone to the computer using the USB cable. The computer will automatically detect the microphone and install the necessary drivers.



2. Windows Setting:

Navigate to Control Panel > System > Sound > Sound Control Panel.

Select "USB Mic Pro" under the "Playback" and "Recording" tabs, and set it as the default device.

3. MAC OS Setting:

Go to System Preferences > Sound.

Select "USB Mic Pro" under the "Input" and "Output" tabs.

Troubleshooting

- 1. Indicator light is off or sound fluctuates.
- **1.1** Ensure the USB plug of the microphone is securely connected and try reattaching it.
- 1.2 When using a desktop computer, it is advisable to connect the microphone to the USB port located at the back of the case.
- 2. Unable to monitor microphone sound.
- **2.1** When connected to a computer, make sure to activate the "Record" function in the system speaker settings and verify that the "Monitor" option is checked under the "USB Mic Pro" device's properties.
- 3. Issues with recording or low sound levels.
- **3.1** Check if the microphone volume for the "USB Mic Pro" device is set too low and adjust it to a normal level.
- 4. Howling noise when connected to a speaker.
- **4.1** If your software or audio equipment includes an echo cancellation feature, ensure it is enabled.
- 4.2 Position the microphone so that its pickup is facing away from the active speaker and maintain a proper distance.
- 4.3 Reduce the volume on both the microphone and the speaker.



This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo