






Porodo Gaming
Ultra-Low Latency Gaming
Earbuds

SKU: PDX419

Table of Contents

Schematic View	2
Power ON/OFF	3
Pairing Instructions	3
Touch Button Function Description	3
Charging	4
Specifications	4
Features	5
Warranty	5
Contact Us	5

Schematic View



Power ON/OFF

Turning On

1. If the earbuds are in the charging case, open the case, and the earbuds will turn on automatically.
2. If the earbuds are turned off, press and hold the earbuds for 3 seconds to turn them on.

Turning Off

1. When the earbuds are powered on, press and hold for approximately 5 seconds to turn them off.
2. Place the earbuds back into the charging case and close the case; the earbuds will power off automatically.

Pairing Instructions

[A] Pairing with Your Phone or Other Devices

1. When the earbuds are in the charging case, open the case, and the earbuds will automatically pair with each other.
2. The blue indicator on the earbuds will flash, indicating they are in pairing mode and waiting for a connection.

[B] Instructions

1. Activate the Bluetooth function on your phone or other device.
2. Search for available Bluetooth devices and select "PDX419" from the list.
3. Once paired successfully, the blue indicator will flash slowly.
4. On subsequent uses, the earbuds will automatically connect to the last paired device (ensure that the device's Bluetooth is turned on).
5. If pairing is unsuccessful, turn off the earbuds and attempt to pair again.

Touch Button Function Description

Play/Pause Music: Single tap.

Previous Track: Double tap the right earbud.

Next Track: Double tap the left earbud.

Increase Volume: Press and hold the right earbud for about 2 seconds.

Decrease Volume: Press and hold the left earbud for about 2 seconds.

Answer Call: Single tap.

Reject Call: Press and hold for about 3 seconds.

End Current Call: Single tap.

Activate Siri: Triple tap the left earbud.

Music/Gaming Mode: Triple tap the right earbud.

Charging

[A] Charging the Charging Case

1. When the blue indicator on the charging case flashes, it indicates low battery.
2. Connect the charging cable to the USB port. It supports 5V power (e.g., AC/DC USB adapter or PC USB port).
3. Plug the cable into the charging port of the case.
4. When the charging case is charging, the blue light will flash slowly.
5. Once fully charged, the blue light will remain solid.

[B] Charging the Earbuds

1. When the charging case is charging the earbuds, the blue light will flash slowly.
2. When the earbuds' battery is low, you will hear a voice prompt to charge them.
3. To charge, place the earbuds into the charging case, and they will begin charging automatically. The blue light will flash slowly during charging.
4. For the first charge, ensure the earbuds are fully charged before use.

Specifications

Battery Capacity	40mAh*2 (Earbuds), 400mAh (Charging Case)
Playtime	6 hours @ %50 Volume
Call Time	5 hours
Standby Time	up to 100hrs
Charging Interface	Type-C
Speaker	Φ10mm
Bluetooth	V5.4
Transmission Range	up to 10m
Frequency Range	2.402GHz - 2.480GHz
Response Time	<60ms
ENC	Dual Mic ENC Support
Hall Switch	Yes

Features

1. The earbuds feature intuitive smart touch controls, allowing you to effortlessly manage music, calls, and volume with simple taps.
2. The earbuds are equipped with customizable RGB breathing lights that create a visually striking effect while enhancing the user experience.
3. With an ultra-low latency of 60ms, the earbuds provide a seamless audio experience, making them ideal for gaming and video watching without lag.
4. Easily switch between game, music, and call modes, ensuring a smooth transition for different activities without the need for manual adjustments.
5. The earbuds utilize ENC technology to effectively reduce ambient noise, providing clearer sound during calls and improving the overall listening experience in noisy environments.
6. The earbuds support Type-C charging, ensuring faster and more efficient charging with a universally compatible connector.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**