

porodo


# Portable DLP Projector

Wireless Mirroring for iOS and Android

User Manual

Model: PD-LSDLPP-BK







Remote Control




Focus



Connection & Key




HDMI




Shortcut



File Manager



Same screen




3D




Audio



WiFi




Language




Bluetooth




Picture mode



Trapezoidal



general settings



Bluetooth speaker




Attention



01—02




03 04



05




06



07 08



9




10—18



19 20



21



22



23




24




25




26




27



28



29




30



31

# Remote Control

## Instruction of Buttons



Note:1. Please keep the remote control aiming at the projector screen.  
2. Please take out the battery if the remote control is not used for a long time.

# How to use the external mouse?




- 1,Click the left button on mouse to enter the screen you have selected.
- 2,Click the right button on mouse to exit the screen you have selected.

# Focus

## Manual focus


1. Quick focus: Long press the button of "F+/"F- on the remote control, the FOCUS icon will appear and rotate quickly on the projection interface.
2. Precise focus: Click the "F+/"F- button on the remote control continuously, and the FOCUS icon on the projection interface will change according to the frequency of clicks.



# Focus



## Autofocus

1. When it is turned on ,the projector will focus automatically .
2. If you want to turn off auto focus on the projector ,please go to settings--Keystone Setting--Focus setting--Auto focus, and turn off the switch of auto focus in the settings interface.
3. If the picture is not clear after you move the projector ,please tilt it up 45°in the vertical (up and down) direction to active the auto focus on the projector.



# Connection & Key

## Touch buttons



# HDMI

## Connect External Multi-media Interface

Connect the HD cord to the projector and click HDMI on the home screen which will appear in sync within five seconds .

**Notes: It can be combined with Amazon Fire TV Stick to connect the projector.**

1. Plug the Fire TV device into projector HDMI port.
2. Check the Audio setting on your Amazon Fire TV or Fire Stick.
3. If you're still experiencing audio issues, try turning off Dolby Digital Plus: On your Amazon Fire TV or Fire Stick, go to Settings > Display & Sounds > Audio > Dolby Digital Output and then turn Dolby Digital Plus OFF.





HDMI





# Shortcuts Button

- 1 Delete the apps you download by pressing and holding down the ok button for two seconds.




# Shortcuts Bottom

2 You can clean the memory by holding the home button for two seconds.




3 Click the mouse button to switch between mouse mode and remote control mode



# File Explorer

Please check the files in File Explorer when you play in your USB.



# Wireless screen (Windows)

## Windows with screen operation guide

1. Please confirm your Windows and projector IP addresses are connected to the same LAN.
2. Use the following link to download and install: <http://cdn.sharemax.cn/app/EShareClient-STD.exe>
3. Click Esharecent-STD, and the name and IP address of the projection device will appear. Click "Start Screen Transmission" to begin using the wireless screen.



1. Connect your device to "Ding Talk"
2. Visit "<http://172.18.1.74:8000>" with web browser or scan the QR-code to download app.
3. Launch EShare and click **EShare-3624** to connect.

# Airplay (iPhone)

## iPhone AirPlay mirror operation guide

Supported by the following devices: iPhone 5 and above, iPad 2 and above, iPod Touch (5th generation and above).

1. Connect your iPhone and projector to the same --WIFI-- network (5G first)



# Airplay (iPhone)

## iPhone AirPlay mirror operation guide

Supported by the following devices: iPhone 5 and above, iPad 2 and above, iPod Touch (5th generation and above).

2. Click to open the projected Airplay, and then Eshare-\*\*\*\* will be displayed in the lower left corner.
3. Slide your finger from the bottom of the iPhone screen to the top, bringing up a new menu, and open the iPhone control center (Slide from the top down for iPhone X),
4. Click AirPlay Mirroring and the device list will automatically search for the projected devices within the same network
5. From the device list, click the name of the projected device you want to connect to (Eshare-\*\*\*\*) to successfully cast the screen.



# Airplay (iPhone)

## Use mobile hotspot for AirPlay mirror operation guide

1. For use without having a LAN or wifi available, first turn on "Settings" -- "Personal Hot spot" -- "Allow others to join" on the iPhone, select and turn on
2. Click "Settings" of the projector -- turn on "WIFI", search for the hotspot name of iPhone, and find and connect.





3. Swipe your iPhone from the bottom up and open the iPhone control center (Slide from the top down for iPhone X).
4. Click "AirPaly Mirroring" and the device list will automatically search for the internal projection device in the same network.
5. From the device list, click the name of the projected device you want to connect to (Eshare-\*\*\*\*) to successfully cast the screen

# Iphone AirPlay reverse

## Screen Projection operation Guide

1. Click to open the projected Airplay, then follow the prompts on the page to scan the QR code of your iPhone, download and install the corresponding Eshare APP.



2. Open the Eshare app on the mobile phone, and the device list will automatically search for the internal projection device of the same network.
3. Click the projection device (Eshare-\*\*\*\*), "one-click screen transmission" and "Reverse screen transmission" will appear simultaneously.
4. Click "Reverse Screen Transmission".

# Wired Same Screen (iPhone)

1. It is best to use the original Apple data cable to connect your iPhone to the USB port of projector .
2. The iPhone will pop up a "Trust " window,please click "Trust " and enter you unlock password to use screen mirroring on phone.





# Wired same screen (Android phone)

1. Please use the original USB data cable to connect your mobile phone to the USB port of your projector .
- 2.A pop-up window appears on your mobile phone that shows the installation of an eShareLine Display app.
- 3.Please follow the instructions on your mobile phone and install eShareLine Display App successfully.
- 4.If the phone shows if the eShareLine Display app is allowed to be used, please agree to this request.




# Android phone Wireless Screen mirroring

- 1 Make sure your Android phone and projector open the WIFI.
- 2 Please click Miracast on the projection screen.



# Android Miracast operation guide

- 3 Open “More Connections or Screen Projection for Android Phone” on the mobile phone (there are a variety of models of Android mobile phones which may have different names, and the mobile phone to be referred is HUAWEI mobile phone).
- 4 The phone and projector will seach for same model in a few seconds and connect successfully.



# How to play 3D movies



For the 3D glasses ,it supports LCD Active Shutter 3D glasses.

Do remember to charge the 3D glasses when you first use it.

For the video format there are 2 options:Side-by-side(SBS) and Top-and-Bottom(TB) format.

To select the correct video format,please refer to the following instructions:

1. Open the 3D video on the projector .
2. Please take out the remote control and press settings button on the remote control.
3. Click 3D button on the left side and choose SBS/TB for your video.





# How to play 3D movies

Example:



For SBS video, you need to open 3D from settings interface and select the SBS option.

For TB video, you need to open 3D from settings interface and select the TB option.





# WIFI Connection

Homepage>Settings>Wifi >Turn on wifi option






# Bluetooth Connection

Homepage>Settings>Bluetooth>Open Bluetooth



# Picture mode



1. Brightness mode: Middle / High/ Low
2. Color temperature: Cool / Warm / User defined
3. Projection mode: Front/Rear/ Ceiling front/Ceiling rear/Auto
4. Stepless zoom: Global / Vertical / Horizontal



# Trapezoidal settings:



Trapezoidal Calibration: Automatic/manual trapezoidal Calibration

1. Automatic Trapezium Calibration: Turn on the automatic trapezoid calibration option and check horizontal 0°calibration option.
2. Manual Setup: Adjust the trapezoidal shape on the basis of the offset. After clicking to restore the default option, the initial state will be automatically reset.
3. Quadrangular Trapezium Calibration: The four angles of trapezoid can achieve the free adjustment, and click “OK” to switch to the next angle, then click the menu key to return to the default settings.





# General settings

1. Wallpaper: General Settings > Wallpaper > Left and right keys to select wallpaper
2. Time zone: General Settings > Time zone > Select your time zone
3. Input method: You can switch different input methods after installing other input methods
4. Fan setting: Automatic / manual




# Sound Settings

- 1、Key Tone: On / Off
- 2、Sound Effect: Standard/ Vivid
- 3、Boot Sound: On / Off



# Select language

Homepage>Settings>Language



# System Settings



System upgrade:

1. Online upgrade /U disk upgrade
2. Restore factory settings: Select restore factory settings (Be cautious)

3. Device information:



Projector model/System version/ UI version/MCU version/ROM/RAM /Eth Mac.

Note: It is not recommended to upgrade built-in APP, which may cause incompatibility problems.




# Online Upgrade

- 1, Homepage>Settings>System Settings>System Upgrade. Before you update ,please connect the power adapter and wifi , otherwise, the update will fail or the system will crash.
- 2, If there is no reaction,please return to settings and try again,after finishing update,the system will turn on automatically.
- 3, If it shows the lastest version of software then the system is up to date.



# Switch to bluetooth speaker mode:

- 1.Turn on bluetooth function on the settings;
- 2.Short press power button on remote control or long press on/off button of machine,select the bluetooth speaker mode then you can start the bluetooth pair and connection to use;
- 3.If you want to stop the Bluetooth speaker,press power button on remote control or on/off button of machine to wake up the projector,and quit the bluetooth connection automatically.



# Attention

For some high version apps, you need to use the mouse to perform comprehensive and fast operations, such as Netflix and YouTube...etc.

