POTODO CHOOSE THE BEST



Porodo 4AC Extension Cable Reel with UK Plug (10m Wire)

PD-4ACEC10M-BK

Operating Instructions

1. Uncoil the Cable: Fully uncoil the cable to its full length to ensure proper heat dissipation during use.

2. Connect to Power Source: Plug the extension reel's plug into a compatible AC 250-220V outlet.

3. Connect Devices: Plug your devices into the extension reel sockets. Do not exceed the maximum loading of 2500W.

4. Power On/Off: Use the extension reel's switch to power on or off the connected devices.

5. After Use: Unplug the extension reel from the power source and devices. Neatly coil the cable for storage.

Safety Instructions

Before using this Extension Reel Cable, please read and understand the following safety instructions to avoid any risk of re, electrical shock, or injury. **1. Inspect Before Use:** Before each use, inspect the entire length of the cable for signs of wear, damage, or exposed wires. Do not use if any damage is detected.

2. Indoor Use Only: This product is designed for indoor use only. Do not expose to water or moisture.

3. Do Not Overload: Ensure the total load on the extension reel does not exceed 2500W to prevent overheating and potential re hazards.

4. Uncoil Before Use: To prevent overheating, fully uncoil the cable before use.

5. Keep Away from Children: Store the extension reel out of reach of children.

6. Do Not Modify: Do not attempt to repair or modify the extension reel yourself. Contact a qualied electrician or the manufacturer for service.

7. Proper Ventilation: Ensure the reel is positioned in a well-ventilated area to dissipate heat effectively.

8. Avoid Physical Damage: Do not bend, stretch, or crush the cable. Avoid running the cable under carpets or doorways where it can be pinched or damaged.

Parameter

Rated Voltage: 250-220V Rated Current: 13A Max Rated Power: 2500W Max Cable Length: 10M Cable Specication: 1*2mm Copper Cable

For more information, please contact our support team:

support@porodo.net

Made in China

f / myporodo

O / porodo www-porodo-net